



DroGo® "B"

REDUCING BLEACH / ANTI-CHLOR

DroGo® "B"

DroGo "B" is a powdered reducing agent that whitens fabric. DroGo "B" is often used with DroGo "A" and is included in the DroGo Kit. DroGo "B" can also be used as an anti-chlor. DroGo "B" should only be used on white fabric.

RESTORATION DIRECTIONS

Before starting, read and understand the DroGo Material Safety Data Sheet.

Fabric to be restored should be stain-free, clean and dry before treatment. Use clean plastic or stainless steel container large enough to allow fabric to be covered with water and move freely.

SHAKE DroGo "B" WELL BEFORE STARTING. Use water temperature and amounts of DroGo "A" and DroGo "B" as recommended on chart below. Mix solution thoroughly. Immerse fabric for time indicated, moving fabric occasionally during treatment. Then rinse fabric thoroughly in lukewarm water, dry and finish in usual manner.

| FOR COLORED FABRICS (Including Whites with Colored Areas) | | | | |
|---|---------------|---------------------------|---------------------------|-----------------|
| Fabric to Be Treated | Water Temp. F | DroGo "A" oz./ gal. Water | DroGo "B" oz./ gal. Water | Time in Minutes |
| Fabric with No Wool | 120 | ½ | None | 60 |
| 100% Wool or Wool Blends | 100 | ½ | None | 60 |

| FOR ALL WHITE FABRICS | | | | |
|--|---------------|--------------------------|---------------------------|-----------------|
| Fabric to Be Treated | Water Temp. F | DroGo "A" oz./gal. Water | DroGo "B" oz./ gal. Water | Time in Minutes |
| 100% Acetate | 120 | ½ | 1 | 30 |
| 100% Acrylic | 100 | ½ | 1 | 30 |
| 100% Cotton or Cotton Synthetic Blends | 120 | ½ | 1 | 60 |
| 100% Nylon | 120 | ½ | 1 | 30 |
| 100% Polyester | 140 | ½ | 1 | 30 |
| 100% Silk | 100 | ½ | ½ | 30 |
| 100% Wool or Wool Blends | 100 | ½ | 1 | 60 |

PRODUCT OVERVIEW

- ◆ DroGo "B" should be used only on all-white fabrics.
- ◆ DroGo "A" is safe for use on most colors and fabrics. Test DroGo "A" on hidden area of garment before using on delicate colors or fabrics.
- ◆ Multi-piece garments or matching sets should be treated together in same bath.
- ◆ Keep Containers sealed when not in use.

* * * * *

ANTI-CHLOR DIRECTIONS

To use DroGo "B" as an anti-chlor, follow the DroGo Restoration Directions above, but use only DroGo "B", eliminating DroGo "A".